

# Assembly Instructions

## Park-It Bike Racks - Inground Mount



- Step 1:** Determine the desired location of unit and mark center of all posts to be mounted, on the ground.
- Step 2:** Move bike rack aside and dig mounting holes 12" wide by 18" deep hole at each post center marked.
- Step 3:** Fill bottom of hole with 4.5" of gravel. Lower unit into holes, making certain the bike racks' above ground height is 36". Fill remainder of holes with cement.
- Step 4:** Support unit with spacers, such as cinder blocks, until cement sets.