



PINNACLE MGP DOUBLE RECEPTACLE ASSEMBLY INSTRUCTIONS


KRC3115
REV. 1
7/11/23




PINNACLE MGP DOUBLE RECEPTACLE ASSEMBLY INSTRUCTIONS




P/N ATR-A0040
(BOTTOM)
QTY. 1




P/N ATR-P0052
(TOP)
QTY. 1




P/N ATR-P0053
(RAIN BONNET)
QTY. 1




P/N ATR-A0050
(INNER SUPPORT)
QTY. 1




P/N ATR-A0043
(LEFT SIDE)
QTY. 1




P/N ATR-A0042
(RIGHT SIDE)
QTY. 1




P/N ATR-A0049
(REAR PANEL)
QTY. 1



P/N ATR-A0044
(LEFT DOOR)
QTY. 1



P/N ATR-A0051
(RIGHT DOOR)
QTY. 1



P/N ATR-A0352
ANGLED SUPPORT
MNTG. BLOCK
QTY. 2



P/N ATR-P0347
(ANGLED SUPPORT)
QTY. 1

**COMPONENTS
REQUIRED FOR
ASSEMBLY**

1/11


PINNACLE MGP DOUBLE RECEPTACLE ASSEMBLY INSTRUCTIONS

P/N ATR-P0334
QTY. 4



L

P/N ATR-P0335
QTY. 6




M

P/N ATR-A0046
QTY. 6



N

P/N CC100-P8
QTY. 4



P

P/N RPCAP025
QTY. 3



Q

P/N DSSF010C250C188
QTY. 2



Z

P/N NFHX025CNUT188
QTY. 12



R

P/N SCBH025C050188
QTY. 22



S


P/N SCBH025C050NYP
QTY. 2



T


THESE LOCKING SCREWS ARE THE ONLY BLACK ONES & HAVE A NYLON PATCH EMBEDDED INTO THE THREADS

P/N SCBH025C150188
QTY. 6




U

P/N SMPT010C125A188
QTY. 6




V

P/N WUSS025WAS188
QTY. 42



W

P/N WUSS025OD125
QTY. 2



X

REQUIRED TOOLS (NOT INCLUDED)

- 1 - 7/16" SOCKET
- 1 - POWER DRILL
- 1 - RUBBER Mallet
- 1 - #2 SQUARE DRIVE BIT
- 1 - 6MM ALLEN WRENCH

NOTE: IT IS IMPORTANT TO KEEP ALL BOLTS FINGER TIGHT DURING ASSEMBLY UNTIL ENTIRE TABLE IS ASSEMBLED.


HARDWARE & TOOLS REQUIRED FOR ASSEMBLY

2/11

PINNACLE MGP DOUBLE RECEPTACLE ASSEMBLY INSTRUCTIONS

STEP 1


BEGIN BY LAYING THE BACK PANEL (G) ON A CLEAN, FLAT SURFACE WITH THE HOLES FACING UP. SET THE BOTTOM PIECE INTO THE LONG SLOT AT THE BOTTOM EDGE OF THE BACK. ATTACH (1) METAL CORNER BRACKET (L) AS SHOWN, BY FIRST SLIPPING IT ONTO THE (2) PROTRUDING STUDS COMING UP THROUGH THE BOTTOM. SECURE WITH (2) FLAT WASHERS (W) AND (2) 1/4-20 NUTS (R). THEN ATTACH THE CORNER PIECE (L) TO THE BACK (G) USING (3) FLAT WASHERS (W) AND (3) 1/4-20 X 1/2" MACHINE SCREWS (S). SNUG THE SCREWS DOWN BUT DO NOT TIGHTEN FULLY YET. DO NOT USE POWER TOOLS. NEXT, ATTACH MOUNTING BLOCK (Y) USING (2) 1-1/4" PANHEAD SCREWS (V) THROUGH THE BOTTOM PIECE.



PINNACLE MGP DOUBLE RECEPTACLE ASSEMBLY INSTRUCTIONS

STEP 2

HOLDING THE BOTTOM UPRIGHT AND STEADY, SLIP THE OTHER CORNER PIECE (L) ONTO THE (2) STUDS PROTRUDING FROM THE CORNER OF THE BOTTOM. AS IN STEP ONE, SECURE WITH (2) FLAT WASHERS (W) AND (2) 1/4-20 NUTS (R). THEN ATTACH THE CORNER PIECE (L) TO THE BACK (G) USING (3) FLAT WASHERS (W) AND (3) 1/4-20 X 1/2" MACHINE SCREWS (S). SNUG THE SCREWS DOWN BUT DO NOT TIGHTEN FULLY YET. DO NOT USE POWER TOOLS.




**ATTACH
BOTTOM**

4/11

PINNACLE MGP DOUBLE RECEPTACLE ASSEMBLY INSTRUCTIONS

STEP 3


INSTALL THE LEFT AND RIGHT SIDE PANELS (E) & (F). THEY CAN BE EASILY MIXED UP, SO INSURE THE TWO ROWS OF HOLES ARE FACING UP AS SHOWN, AWAY FROM THE BACK PANEL. SECURE USING (3) FLAT WASHERS (W), AND (3) 1/4-20 X 1/2" MACHINE SCREWS (S), PER BRACKET, AS SHOWN. HAND TIGHTEN. DO NOT USE POWER TOOLS.



**ATTACH
SIDES**

5/11

PINNACLE MGP DOUBLE RECEPTACLE ASSEMBLY INSTRUCTIONS



STEP 4


WITH THE RECEPTACLE STILL LAID ON IT'S BACK, ATTACH THE SUPPORT ARCH (D) TO THE INSIDE OF THE UNIT WITH (3) FLAT WASHERS (W) AND (3) 1/4-20 X 1/2" MACHINE SCREWS (U) PER SIDE. ANOTHER PERSON SHOULD HELP HOLD THE ARCH IN PLACE DURING THIS STEP. HAND TIGHTEN ALL (6) SCREWS. DO NOT USE POWER TOOLS. INSTALL ANGLED SUPPORT PIECE (K) AT LOWER REAR CORNER TO THE CENTER OF THE ARCH PIECE ON TOP. JUST WEDGE IT INTO PLACE FOR NOW. ATTACH AT LOWER END WITH ONE 1-1/4" PANHEAD SCREW (V) AND JUST WEDGE THE TOP END INTO THE ARCH FOR NOW.

PINNACLE MGP DOUBLE RECEPTACLE ASSEMBLY INSTRUCTIONS

STEP 5

WITH THE UNIT STILL LAYING ON IT'S BACK AND THE SIDES NOW ATTACHED TO THE ARCH SUPPORT, SECURE THE BOTTOM OF THE ARCH TO THE BOTTOM OF THE UNIT USING (2) #10 X 1-1/4" PANHEAD SCREWS (V). HAND TIGHTEN THROUGH THE HOLES PROVIDED IN THE BOTTOM AS SHOWN.

NEXT, SECURE THE TOP END OF THE ANGLED SUPPORT INSIDE THE UNIT. USE (2) #12 X 2-1/2" SCREWS (Z) TO ATTACH THE MOUNTING BLOCK TO THE BACK SIDE OF THE ARCH USING THE PILOT HOLES PROVIDED. THEN SECURE THE TOP OF THE ANGLED SUPPORT TO THE SIDE OF THE BLOCK USING (1) #10 X 1-1/4" PANHEAD SCREW (V). HAND TIGHTEN.




**SECURE
INNER
SUPPORT**

7/11

PINNACLE MGP DOUBLE RECEPTACLE ASSEMBLY INSTRUCTIONS

STEP 6

PREASSEMBLE THE TOP AS A SUBASSEMBLY BEFORE ATTACHING TO THE UNIT ITSELF. BEGIN BY LAYING RAIN BONNET (C) UPSIDE DOWN ON A CLEAN, LEVEL SURFACE. INSERT (6) THREADED RODS (N) INTO THE METAL INSERTS, USING THE NUT AS A STOPPING POINT. (SEE DETAIL A). PLACE (1) TUBE (M) OVER EACH OF THE THREADED RODS. NEXT, CAREFULLY PLACE THE TOP (B) ONTO THE RODS, AIMING EACH ROD INTO ITS RESPECTIVE HOLE. THE TOP (B) MUST BE ORIENTED CORRECTLY, WITH THE METAL INSERTS IN ITEM (B) FACING AWAY FROM THE RAIN BONNET (ITEM C). WHEN THE RODS ARE ALL IN THE HOLES, INSERT (3) FLAT WASHERS (W) AND (3) 1/4-20 LOCKING NUTS (R) ONTO THE BACK 3 RODS ONLY. THE BACK IS THE EDGE WITH 2 CORNER HOLES, NOT ONE. TIGHTEN JUST UNTIL NUTS BOTTOM OUT.




SCREW THE RODS IN UNTIL THE NUT BOTTOMS OUT.

DETAIL A
SCALE 1 : 4

**ASSEMBLE
TOP**

8/11

PINNACLE MGP DOUBLE RECEPTACLE ASSEMBLY INSTRUCTIONS



STEP 7

WITH MAIN UNIT TURNED UPRIGHT AGAIN, LIFT THE PREASSEMBLED TOP ONTO THE UNIT, ALIGNING THE FRONT RODS INTO THE (3) HOLES IN THE TOP PART OF THE ARCH. SINCE THE TOP ASSEMBLY IS ONLY HELD TOGETHER WITH (3) FASTENERS AT THIS POINT, CARE MUST BE TAKEN TO KEEP IT TOGETHER. ONCE THE (3) FRONT RODS ARE FULLY ENGAGED INTO THE HOLES IN THE ARCH, FASTEN THEM USING (3) FLAT WASHERS (W) AND (3) 1/4-20 LOCKING NUTS (R). DO NOT TIGHTEN YET. NEXT, SECURE THE BACK CORNERS TO THE TOP OF THE CORNER PIECES USING (2) FLAT WASHERS (W) AND (2) 1/4-20X 1/2" LONG MACHINE SCREWS (S) PER CORNER.


**ATTACH
TOP**

9/11

PINNACLE MGP DOUBLE RECEPTACLE ASSEMBLY INSTRUCTIONS

STEP 8


INSTALL THE (2) FRONT CORNERS (L) AS HINGES, SECURING THEM ONLY THROUGH THE CENTER HOLES ON EACH END. PLACE (1) OVERSIZED 1/4" FLAT WASHER (X) ONTO EACH BOTTOM STUD. NEXT, DROP LOWER END OF ITEM (L) ONTO STUD. ALIGN TOP END OF ITEM (L) WITH METAL INSERT IN FRONT CORNERS OF TOP. ONCE ALIGNED, SECURE TOP END USING FLAT WASHER (W) AND SPECIAL LOCKING SCREW (T) WITH NYLON LOCKING PATCH EMBEDDED INTO THE THREAD. TIGHTEN JUST ENOUGH TO BOTTOM OUT THE SCREW HEAD. GO BACK AND SECURE THE BOTTOM END USING (1) FLAT WASHER (W) AND (1) LOCKING NUT (R) PER CORNER.



**ATTACH FRONT
HINGES**

10/11

PINNACLE MGP DOUBLE RECEPTACLE ASSEMBLY INSTRUCTIONS



STEP 9

ATTACH LEFT AND RIGHT DOORS (ITEMS H & J) USING (3) FLAT WASHERS (W) AND (3) 1/4-20 MACHINE SCREWS (S) PER DOOR. HAND TIGHTEN. DO NOT USE POWER TOOLS. NEXT, INSTALL THE MAGNETIC LATCHES USING THE SCREWS PROVIDED WITH THE LATCHES. BECAUSE OF VARIANCES IN THE SIZE OF THE LATCHES, HOLES WERE NOT PRE-DRILLED FOR THE SCREWS. HAVE ONE DOOR CLOSED AND ONE DOOR OPEN. POSITION THE MAGNETIC LATCHES ON THE BOTTOM AND TOP, MARK SCREW LOCATIONS, AND DRILL A 1/4" DEEP HOLE. **DRILL HOLES 1/4" DEEP ONLY!** INSTALL LATCHES. THEN DO THE SAME FOR THE OTHER DOOR, TOP AND BOTTOM. GO BACK AND MAKE SURE ALL FASTENERS ARE TIGHT. DO NOT USE POWER TOOLS. IF NECESSARY, LOOSEN THE SCREWS ATTACHING THE MAGNETIC LATCHES AND ADJUST FOR A BETTER FIT. THEN RETIGHTEN.

CONGRATULATIONS! YOU HAVE ASSEMBLED YOUR PINNACLE MGP DOUBLE RECEPTACLE ENCLOSURE.





**ATTACH
DOORS**

11/11

PINNACLE MGP DOUBLE RECEPTACLE

KRC3115
REV #1
7/11/23

ALL DIMENSIONS ARE SHOWN IN INCHES



NOTE: ALL MATERIAL IS RECYCLED PLASTIC LUMBER UNLESS NOTED